

wile²⁵



EN

Operating instructions

Wile 25 OPERATING INSTRUCTIONS

1. Box Contents

- wile 25 moisturemeter
- carrying case
- carrying strap
- operating instructions
- 9 v 6F22 (installed)

2. Features

The Wile-25 will provide moisture content information for hay, silage and forage when measuring bales of hay, forage in a bucket and also loose hay.

There are two different probes available for W-25. Wile 251 probe for measuring bales and Wile 253 dishprobe for measuring loose hay (probes needs to be ordered separately).

The meter shows the water content of the sample in percentage of weight. The definition of moisture is based on measuring the loss of a high frequency alternating current signal (capacitance) in the sample., The repeatability of the result is +/- 2,0 percent of moisture or better

Wile 25 meter is calibrated to give uniform results with the official methods that are used for defining the moisture content in hay and silage.

The calibrations are defined with samples that represent the most common available qualities of hay, silage and other varieties of grass.

Moisture range:

loosehay: 13-85 %

baled hay: 10-73 %

Bale density

80-250 kg/m³ (with 10 kg
graduating)

Features

- Automatic compensation of the temperature difference of the meter and the environment
- Average calculation of measurements
- Adjust calibration to match the meter reading with a reference result.

3. MEASUREMENT

3.1 Preparation

When the meter is not used for a long time:

- Replace battery (See 6. "**Battery**")
- Read this manual
- Check you meter (See 5. "Control, care and maintenance")

3.1.1 Bales and measurements

In big bales the chances of varying moisture is greater so always make 5 readings per bale to get an average. In small traditional bales it is normally enough to do one measurement.

Always double check any high readings, when you deal with dry hay or straw.

If you find moist spots, immediately take action to prevent further damage.

Please note that spoiling hay may heat up dangerously.

3.1.2 Choosing probe

Read the instructions printed on the side of the moisture meter when choosing the right probe.

Probe1 – wile 251 for baled hay



Wile 251, length 45 cm, is ment for big and small, rektangular or round bales. (see 3.2.2 baled hay)

Probe 2- wile 252

Wile 252, length 90 cm, for baled hay. Outbound product at the factory.

Probe 3 – wile 253 for loose hay




Wile 253, dishprobe for loose silage or hay. Measuring in a bucket (see 3.2.1 loose hay).

3.2 Processing the sample and using the probe

3.2.1 Loose hay


Always do several measurements of the chosen batch. Take a handful from different plases of the swoth and fill a bucket. Press the hay or silage in to dense layers in the bucket with your hand before measuring. Press the dishprobe(number 3 in the meter) into the bucket with a force of 20 kg.

Its important to press the dishprobe the whole measuring time (20sek.)



3.2.2 Baled hay

Choose wile 251 probe for baled hay (number one 1 in meter).



In smaller bales its enough to meaasure once but in bigger bales you need to have several measurements. Take the readings from different spots from the bale.

When measuring round bales you need to take readings from several spots.

You need to estimate the density of the bale to get correct moisture readings.

3.2.3 Define the density of the bale

To define the density, you need to know the weight and volume of the bale. Divide the weight of the bale (kg) with its

volume (m³), the result is the bale density in kg/m³

Rectangular bales

Length x Height x Width = Volume

Weight ÷ Volume = Density kg/m³.

Large round bales

Distance across the bale centre ÷ 1.273

x Width = Volume

Weight ÷ Volume = Density kg/m³.

3.3 Measuring

Connect the right probe to the meter and then press P. Meter shows now the number of the probe that is connected. When needed change the number according to chapter 3.4.1 (Choosing probe in the meter). The meter will now show you the density reading. When needed change density reading according to chapter 3.4.2 (density settings). The meter starts measuring and shows moisture readings shortly. The meter considers the temperature of the sample and how it effects the moisture readings. The meter turns off itself after the measuring. Always do several measurements cause moisture can vary in different parts of the bale.

3.4 Measuring Instructions

Press P to turn meter on. Meter shows shortly all the available symbols and marks.



Probe in use follows in display



Density for the bale follows ex. 120kg/m^3 .
Change density when needed.

120

Run apparatus in display and meter starts measuring the moisture content.

Moisture readings shown in percentage
ex, 28.8

run

28.8

After measuring meter turns off itself. The meter is now ready for the next measurement.

By doing several measurements from the sample you insure the average quality of the bale.

3.4.1 Choosing probe in the meter

The list of the available probes is on the side of the meter. Choose the right probe. There is also a "probe 0" (basic scale) that will - service will use.

"Probe – 0" is a basic scale that can also be used for table scales. When using Probe – 0 you do an ordinary measuring and see the identical moisture readings from the table. You will get the table scales from the manufacturer or the local will-dealer, also see www.wile.fi.

Check the number of the probe when probe connected by pressing P. You will shortly see the number of the probe in the display. Ex, -1-

You can change the probe by pressing F.

- 1 -

After this meter shows density settings and run. Meter is ready for measuring.

run

3.4.2 Density settings

After calculated the density of the bale set the right density in the meter.

Press p to turn meter on. Meter shows now probe in use and the density used last time ex. 120 kg/m³.

120

You can change density by pressing F and increase 10 kg/m³ by every press. (250 is the last value)

4. Processing of the results

4.1 Average calculation

The meter can store and calculate an average value of several measurements. After a measurement you can add the result to the average calculation.

4.1.1 Adding a result to the average calculation

When the result is shown on the display, Press F. Now A will be on the display, the meter has included the latest result to the average.

A

Calculation is ready when A05 and 28,8 are alternating on the display

A05

28.8

It means the following:

A05 – The avg. is based on 5 measures

28,8 - The avg. moisture % of the results.

If you don't want to include the results just wait and the meter will automatically switch off. Then just start again.

Before using the average calculation, always check that the average memory is empty. Delete if necessary.

4.1.2 Delete the average memory

Method 1. When the average value is displayed, press **F** and keep it pressed until you see **0** and after that **A00**

Method 2. Press **F** and keep it **depressed** then press **P**. When you see **A** on the display, release the **F** button. If you now see an average value, you can erase it by keeping the button **F** depressed until you see on the display **0** and after that **A00**.



A00

Please note! It is a good practice to **erase the average memory after completing a measuring session. This prevents any old values affecting later measurements.**

The avg. memory blinks If it is full.

4.2 Adjusting the calibration

If you have had a sample tested in an oven and the moisture is different to what the meter reads. Then you can adjust your meter match the oven test, and this adjustment can remain in the

settings to change future measurements.

The calibration can be adjusted up and down.


4.2.1 If you want to add the result

Press **F** twice when the result is on the display. Three bars will appear on the top of the display and after that the moisture reading. Now add 0,1 percent to the result with each press of **F**.



4.2.2 If you want to deduct from the result

Press **F** three times when the result is on the display. Three bars will appear on the bottom of the display and after that the moisture reading. Now deduct 0,1 percent from the result with each press of **F**.



Please note! The adjustment of the calibration is specific for each probe.

4.2.3 Adjustment of the calibration

An adjustment to the calibration will appear on the display after the next **run**.

E.g. **"-.5"**. - 0,5 per cent units have been deducted from the result before displaying it.

Please note: the proceeding zero is not displayed



E.g. "1.5" - 1.5 per cent units have been added to the result before displaying it.





4.2.4 Removing the adjustment

Press **F** and keep it depressed until the reading changes. Now the adjustment is removed.

4.3 Result out of range

HI is displayed if the result is over the upper limit of the measurement range

LO is displayed if the result is below the lower limit of the measurement range



Moisture range for loose hay is between 13-85 % and 10-73 % for baled hay.

When getting HI or LO result always check that you are using right probe and also do some check measurements.

5. Control, care and maintenance

All Wile 25 moisture meters are calibrated when manufactured. Before the season starts check the meters basic functions. After pressing P it should read



After that you will see

- number of the probe
- the density (probes 1 and 2)
- run
- result adjustments (if done and if probe 1 and 2 are seen in the

- display.
- Moisturereadings

With Wile 251 baleprobe you can check meters readings/calibrations.

Connect the probe to the meter. Turn on the meter and coose scale -0-. Hold up the the probe in the air. Probe W251 needs to be between value 2000 +/- 5, that meens betwween 1995-2005.

The biggest reading in the display is 1999 and its followed by 000. 003 means 2003 and 005 means 2005. If wierd readings occurs , please send the meter manufactorer or wile-dealer.

6. Battery

The meter works with a 9 volt 6F22 battery or an alkaline battery of the same format. A battery is included in the delivery.

LOBAT-sign at the upper left corner of the display indicates that the battery should be replaced



Replace the battery as soon as possible. If the battery is nearly empty, the LOBAT sign may not be seen any more.

To replace the battery, open the lid of the battery compartment, in the bottom of the meter. Take out the battery and disconnect it from the connector and reconnect the new battery and close the lid.

Always first check the battery if you suspect any problems with the operation of the meter. Please note that the batteries

discharge themselves slowly even if the meter is not used.

7. Service, warranty and storage

This product carries a one (1) year manufacturer warranty for materials and workmanship. The warranty is valid for one (1) year from the date of purchase on the receipt.

To claim the warranty, the customer should return the defect product to the Manufacturer, reseller or the nearest Wile Service Partner at customer's own expense. The warranty claim must be accompanied by the description of the fault, copy of the sales receipt and customer's contact information. The manufacturer / Wile Service Partner will repair or replace the defect product and return it as soon as possible.

The warranty does not cover any damages that are caused by incorrect or careless use of the product, installation that does not correspond to the provided instructions and other damages which may arise due to causes beyond the control of the manufacture.

Farmcomp does not accept any responsibility for any direct, indirect or consequential damages that are caused by the use of the product or the fact that the product could not be used. The liability of Farmcomp is limited to the price of the product in maximum.

Store the meter in some dry place. Don't drop the meter. If you suspect failure in the product check first the battery.

**Declaration of Conformity
according to ISO/IEC Guide 22 and EN
45014**

Manufacturer's name: Farmcomp Oy
and address: Jusslansuora 8
FIN-04360
TUUSULA, FINLAND

declares, that the product

Product name: Moisture tester
Model numbers: Wile 25

*conforms to the **EMC directive**
2004/108/EC by following the
harmonised standard*

EN 61326-1:2006



Tuusula, Finland
July 22, 2010

Lasse Paakkola
Managing Director

Original language: Finnish
Signed Declaration of Conformity
documents are filed at Farmcomp Oy

Farmcomp Oy, Jusslansuora 8,
FIN-04360 Tuusula, Finland
tel +358 9 77 44 970,
e-mail: info@farmcomp.fi
Company ID FI 07308235 Tuusula,
Finland



FARMCOMP OY
Jusslansuora 8 TUUSULA, FINLAND
Tel. +358 9 7744 970 Fax +358 9 7744 9744
FI-04360 info@farmcomp.fi
<http://www.wile.fi>

Copyright Farmcomp Oy 2010, all rights reserved